



# DRIVESAFE™

Breath Alcohol Tester





# DRIVESAFE™ Breath Alcohol Tester

DRIVESAFE provides accurate results in seconds using a reliable semi-conductor sensor and user friendly design. Law enforcement, healthcare and transportation professionals have trusted the accuracy and convenience of this alcohol tester for more than 15 years.

## Easy to View Display

DRIVESAFE uses a tri-colour analog meter up to 0.15 %BAC which can be backlit for dark conditions.

## Trusted Semi-conductor Sensor

Using a patented semi-conductor sensor, DRIVESAFE is capable of accurately analyzing thousands of breath alcohol tests\*. The sensor also allows for easy calibration using any approved simulator and alcohol reference solution.

## Immediate Results

DRIVESAFE completes a diagnostic check and purge cycle in less than 30 seconds. After the purge cycle, blow into the mouthpiece for five seconds and the alcohol result will be displayed immediately.

## Warranty

ACS breath alcohol testers are warranted to be free from defects in workmanship and material for one year from the date of purchase. It is recommended that only qualified technicians perform maintenance of any breath alcohol tester.

\*All breath alcohol testing devices require periodic maintenance and calibration to ensure proper working order.

## Specifications

Size:	133 mm x 70 mm x 38 mm
Weight:	150 grams
Sensor:	Semi-conductor
Specificity:	Selective to alcohol
Temperature Range:	0°C to 40°C
Purge Cycle (Initial Test):	30 seconds
Breath Sample:	6 second continuous sample
Analysis Time:	< 8 seconds
Recycle (Recovery) Time:	20 to 60 seconds
BAC Readout Format:	%BAC, promille, mg/L, mg%
Range of Measurement:	0 to 150 mg%
Accuracy:	± 10 @ 100 mg%
Display:	Tri-colour analog meter
Battery Pack:	6 x AA alkaline (included)
Number of Tests:	250 + with new batteries
Automatic Power Down	After 30 seconds
Mouthpieces:	Round (model: 95-000140)
Calibration:	Alcohol/water simulator



ALCOHOL COUNTERMEASURE SYSTEMS

Alcohol Countermeasure Systems Corp

60 International Boulevard Toronto, Ontario M9W 6J2 CANADA

T 416 619 3500 F 416 619 3501 info@acs-corp.com acs-corp.com